

# XP-Pen LED Light Pad

CP Series A4S Manual




Any questions, please contact us

Skype: XP-Pen Web site: www.xp-pen.com Mail: service@xp-pen.com







www.xp-pen.com



# **User Manual**

Thank you for purchasing the XP-Pen CP A4S LED light pad. XP-Pen is dedicated to designing and creating high quality products that are environmentally and human friendly.

The CP A4S LED light pad features a soft backlight using LED technology, which provides a cool light source gentle to eyesight.


### 1. How to use the CP A4S LED light pad?

(1) Please check if all the included items are in the box.



- 1. Active area
- 2. Switch touch
- 3. LED
- 4. Power jack
- 5. Port A
- 6. Port B

(2) Take out the copy pad and power adapter, insert the power adapter into an AC outlet.



(3) Plug the power adapter into the power input jack of the light pad, then press and hold the touch switch button briefly to turn the light pad on; press and hold the touch switch button again to turn the light pad off.






4) Brightness adjustment: when the light pad is on, press the switch touch button continuously, which will toggle the light/dark adjustment settings of the screen. When you have chosen your ideal brightness, simply stop pressing the Roller button and the light pad will now be set to that brightness.



(5) Brightness memory function: Whenever you turn the light pad on, it will set the screen brightness automatically to your last setting.



#### Notes:

- (1). When you plug adapter into the power jack and the CP A4S LED light pad is turned off, the blue LED light will turn on.
- (2). When you turn on the CP A4S LED light pad, the blue LED light will turn off.

### 2. CP A4S LED light pad product features

- (1) The XP-PEN LED Light Pad utilizes LED backlight technology. The Cold light source is gentle to protect your eyes from harmful damage over prolonged use. The light pad has little to no heat generation, providing a consistent comfortable working temperature for long-term operation.
  - The XP-PEN LED Light Pad features a High-quality acrylic screen panel that is very durable and scratch-resistant.
- (2) The XP-PEN LED Light Pad contains a touch Intelligent IC wafer inside the light guide panel (touch switch button), which has the function of adjusting the screen brightness. The touch switch button is of fashionable appearance, energy conservation, convenience and considerate design.



#### 3. CP A4S LED light pad Specifications:

LED Light Pad-A4S	
Dimension(L x W x H)	360 x 265 x 7mm
Active area	12.4" x 8.6"
Working surface	PC
Light source	LED
Working voltage	DC 5V
Electric current	440mA
Guide light way	High-quality acrylic light panel
Scale size	Yes
Net weight	0.79 KG
LED life cycle	6500-7000K
Working temperature	Active area no more than 30°C,marginal area no more than 37°C
Maximum life time	60000 hours
Warranty	15 months
Characteristics	Eye-Protection, Ultra-thin, Intelligent adjustment, Memory function
Rated power	5W

#### 4. Friendly Reminder

- (1) The first time you use this product, if the Roller button doesn't function, disconnect the power cable, and then reconnect the power cable 5 seconds later. The IC wafer will re-identify the panel and generate memory to work properly.
- (2) If the Roller button's sensitivity is weak: cut off the power switch, and gently press the switch touch, then reconnect the power.
- (3) If the light source does not shine at all or shines improperly, there is possible mechanical malfunction. Please do NOT disassemble the product; Return it to the factory or your local after-sales service center for maintenance.
- (4) Make sure the power voltage at your current location is the same as your power adapter (100-220V).

## 5. Safety Tips:

- (1) The light pad should be kept away from heat sources such as radiators, ovens, stoves, microwaves, etc.
- (2) Do not use or place the light pad in areas with moisture, corrosion, high temperature, dust, strong magnetic interference, etc.
- (3) Avoid the light pad from being beaten, hit, squeezed, severe vibration, etc., in order to prevent damage to the product.
- (4) This product contains small parts, please keep it away from little children and animals.
- (5) Do not dismantle the parts of the product; If damages are caused, the warranty will be invalid.



#### 6. After-sales service:

(1) 15-month-warranty from the date of purchase.

(2) In the case that your device breaks down or is destroyed for any reason that goes against the operation instructions such as dismantling the device, collision, impact with the water, fire, Lightning and earthquake, etc. NO free warranty service will be provided.

If you have any questions, please contact us at:

Skype: XP-Pen

Web: www.xp-pen.com

Email: service@xp-pen.com